

# Motorola T900

## Quick Start Guide

### TURNING PAGER ON

- Open the flip and press any key to turn your pager on. The pager emits a 4-second power-up alert, and the Status screen displays.

### TURNING PAGER OFF

- From the Main menu, press  or  to highlight **POWER OFF** and press  ENTER.
- Highlight **YES** and press  ENTER.

### READING MESSAGES

- To read a message, (while previewing) press  or  to highlight the desired message and press  ENTER.
- Press  or  to scroll through the text of a message or press  ENTER to page through the message.

### COMPOSING AND SENDING A MESSAGE

- From the Send Message menu, press  or  to highlight **WRITE MESSAGE** and press  ENTER.
- After you finish composing the message, press  ENTER.
- To send, return to the Send Message menu, press  or  to highlight **SEND MESSAGE** and press  ENTER.

## DELETING A MESSAGE

- From the Main menu, press  or  to highlight the inbox containing the messages you want to delete and press .

## SETTING THE DATE AND TIME

- From the Main menu, press  or  to highlight *PREFERENCES* and press .
- Press  to highlight *SET TIME & DATE* and press .
- Press  or  to change the hour, minutes, and date. Press  or  to move between fields.

## SETTING THE ALARM

- From the Main menu, press  or  to highlight *PREFERENCES* and press .
- Press  or  to move between fields and  or  to increase or decrease the value in each field.
- At any time, press  to save the changes and return to the Preferences menu. Or press  to exit without saving your changes.

## PRIVATE TIME

- From the Main menu, press  or  to highlight *PREFERENCES* and press .
- Press  or  to highlight *PRIVATE TIME* and press .
- Press  or  to activate Private Time mode.



Power on



MailBox



News/Info InBox



Send Message



Info-On-Demand



Address Book



Personal Folder/Move  
message to folder



News/Info Folder



Preferences



Vital Signs



Power Off



Message has been read



Message reply



Reply in progress



Delete Message/Inbox



Successful Reply/Send



Unsuccessful Reply/Send



Message contains custom  
reply choices



InBox



InBox - messages read



News/Info InBox



InBox alert selected



Out of Range



Low Battery



Audible Alert/Alarm



Vibrate Alert/Quiet Mode



Private Time



Signature

|                                                                                     |                                        |                                                                                   |                   |
|-------------------------------------------------------------------------------------|----------------------------------------|-----------------------------------------------------------------------------------|-------------------|
|   | MailBox Alert, News/Info Alert         |  | Message Memory    |
|  | Alarm/Set Alarm                        |  | About Screen      |
|  | Set Time & Date                        |  | Back/Escape       |
|  | Alert Volume/Key Click, Reminder Alert |  | Yes/On            |
|  | Transmitter Off                        |  | No/Off            |
|  | Next/higher value                      |  | News AutoPreview  |
|  | Preceding/lower value                  |  | Set InBox History |
|  | Previous item                          |  | Next Message      |
|  | Next item                              |  | CAPS (not locked) |
|  | Move InBox Up                          |  | CAPS Lock on      |
|  | Move InBox Down                        |  | Alt (not locked)  |
|  | Battery Gauge                          |  | Alt Lock On       |

**Note:**

A flashing icon denotes unread messages or a function in process.